



# Mesh Back Office Chair Instructions


Brand : KOHL

Model: G23H (carpeted floor) | G23W (hard floor)

## Custom Comfort at Work with the KOHL Mesh Back Office Chair

Designed to accommodate individuals of all shapes and sizes, this chair offers a range of customizable features. Take a look at the diagrams below to discover how easily you can tailor your comfort to meet your unique needs.

### USAGE INSTRUCTIONS



1 Seat Height Adjustment

2 Backrest Tilting Resistance Adjustment  
(Pullout for Easier Operation)

3 Seat Angle Lock / Release

4 Seat Slider Lock / Release

5 Backrest Inclination Lock / Release  
(Pullout for Easier Operation)

6 Armrest Height Adjustment

7 Armrest Pivot Adjustment (By Hand)

8 Armrest Width Adjustment

9 Armrest Depth Adjustment

10 Lumbar Support Adjustment

11 Backrest Height Adjustment

### MAINTENANCE

To keep your KOHL Mesh Back Office Chair in excellent condition, follow these guidelines:

- 1) Regularly clean all moving parts, especially castors, to remove dust and dirt.
- 2) Tighten screws every six months or as needed for stability.
- 3) Clean fabric/mesh with a damp cloth and mild soapy water. Avoid harsh cleaners.
- 4) Gas lift and mechanism should be repaired or replaced by an approved service person.
- 5) Assigned castors provided are suitable for either hard or carpeted floors.

### SAFETY PRECAUTIONS

- Ensure that all adjustments and locking mechanisms are properly engaged before sitting in the chair.
- Do not exceed the weight capacity of the chair.
- Avoid standing on the chair or using it for any purpose other than intended.